

G2 GRILL STAND ASSEMBLY INSTRUCTIONS

WWW.COOKWITHKENYON.COM

KENYON[®]

Make any day a weekend

Manual #145757
Revised: February 12, 2025

PLEASE READ THESE INSTRUCTIONS IN THEIR ENTIRETY BEFORE USE. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

ITEMS REQUIRED



Phillips Head Screwdriver



Hex Screwdriver (Included)



Gloves and a Helping Hand Strongly Recommended

HARDWARE




S1 (18X)
#8-32 x 5/16"
Hex Drive




N1 (1X)
#6-32 Locknut




S2 (13X)
#6-32 x 1/2"
Phillips Head




S5 (1x)
#6-32 x 1-3/8"
Phillips Head



S3 (2x)
1/4"-20x 3/8"
Phillips Head



Hooks (4X)



E1 (4X)
Elevator Bolt
Optional









S4 (4X)
1/4" x 1-1/4"
Hex Head
Optional



Casters (4X)
Optional


Thank you for choosing **Kenyon**, the world's leading manufacturer of specialty cooking appliances. By following the instructions in this assembly manual, your grill stand will provide you with many years of reliable service.

Part List

SIDE SHELF ASSEMBLY	SIDE ASSEMBLY
	
STATIONARY SHELF	TOP ADAPTER PLATE
	
SIDE TRAY	TOP FRAME
	

If any components are missing or damaged, please call KENYON Customer Service at 860-664-4906.

Assembled Stand



Assembling G2 Grill Stand


1) Assemble stand on a carpet or soft surface to avoid any dents or scratches.

Kenyon recommends using gloves during assembly.

Unpack stand parts carefully and lay the parts out to check for shipping damage.


2) Place Side Assembly and a Top Frame Panel on a flat surface. Align the top hole on the Top Frame Panel with the top hole of the leg (contained within Side Assembly). Fasten 2X of screw S1 to the corresponding holes 1 & 2 as shown in the figure below.

Use: 2X Screw S1




3) Align the top hole of the remaining Top Frame Panel with the top hole of the opposite leg from Step 2 on the Side Assembly. Fasten 2X of screw S1 to the corresponding holes 3 & 4 as shown in the figure below.

Use: 2X Screw S1



4) Align the Side Shelf Assembly top holes with the top holes of the Top Frame Panels. Use 4X of screw S1 to fasten the Side Shelf Assembly to both Top Frame Panels using holes 5,6,7 & 8 as shown in the figures below.


Use: 4x Screw S1



Instructions


5) Remove vinyl covering from the Stationary Shelf before installation. Slide the Stationary Shelf between the legs of the stand as shown in the figure below. Fasten 8X of screw S1 to the 2 holes in each of the 4 legs. Do not fully tighten the S1 screws until all 8 screws are fastened to the legs.

Use: 8X Screw S1




7) Fasten 2X S3 screws to the corresponding holes 9 & 10 as shown in the figure below. Do not tighten all the way. Place Side Tray onto Side Assembly by aligning the keyholes on the Side Tray with the 2X S3 screws.

Use: 2X Screw S3




6) Place the Top Adapter Plate on top of the stand assembly. Use the label on the part to place the plate in the correct orientation. Use 12X S2 screws to fasten the plate to the stand. Do not fully tighten the S2 screws until all 12 screws are fastened to the Top Adapter Plate.

Use: 12X Screw S2



8) Place your G2 Grill on top of the stand as shown in the figure below.



Instructions

9) Optional: Fasten the G2 Grill to the Top Adapter Plate using 1X S5 screw and 1X N1 nut. Line up the hole in the bottom pan of the G2 Grill with the hole in the Top Adapter Plate.

Use: : 1X Screw S5 & 1X Nut N1


10) There are three options for this step:

A) If using the elevator bolts, screw E1 into the bottom of each leg and adjust for leveling. Use the jam nut to secure the elevator bolt in place.

B) If fastening the Stand to a deck or patio, find the install location to set the Stand. Use screw S4 to fasten in place.

C) If using the casters, fasten into the bottom of each leg. Each caster includes a brake to secure the stand in place.

Use: 4X Screw S4, OR 4X Elevator Bolt with Jam Nut E1, OR 4X Casters



11) Congratulations, your G2 Grill Stand has been assembled! Take this time to tighten all fasteners.

12) The Folding Shelf can be lifted and lowered into position by lifting both levers on the brackets underneath. Although there are rubber caps on the levers to protect your stand, do not let the Folding Shelf fall into the down position.

13) Carefully remove the remaining vinyl, pulling it off slowly to avoid leaving residue behind. Use this time to clean and polish the grill and stand for a beautiful shine. Always wipe with the grain—never across or diagonally.

14) This package includes four Hooks, which can be used to hang your grilling accessories wherever you like, inside or outside the stand. Keep in mind that once attached, they cannot be removed without damaging the surface. They use high-bond tape, ensuring a strong hold. Before applying, thoroughly clean the desired area. Peel off the protective layer from the double-sided tape on the back, then press firmly into place. Allow at least two hours for the adhesive to set before adding any weight.

Congratulations, go grill your favorite food!
If you have any questions or concerns while assembling, please do not hesitate to call Kenyon customer service at 860-664-4906.